


Product Overview



1 Power the Unit

Power the unit with 12 VDC.
(Use B+B SM16-12-V-P230-C1)

2 Connect Serial Cables

3 Operation

Data flow from master port to slave ports

All data that is sent to the TX line, pin 3 on the master port, is broadcast to both slave ports under all conditions. This data appears on pin 2 of each slave port.

Data flow from slave ports to master port.

Data that is sent to the TX line (pin 3) on the slave ports must compete for the path to the master port. There are two

methods of capturing the path to the master port, RTS and automatic data sensing. The first slave port to either raise its RTS line or transmit data captures the path to the master port. The path will be locked on that slave port until it either lowers its RTS line, or 60 milliseconds after the end of its transmission. Note that the 232PTC does not buffer any data, any data sent to the opposite slave port during this period will be lost.

Handshake signals

The CTS signal on each slave port indicates to the slave devices if the path to the master port is available. If the slave port's CTS line is high, data received by that port will be transmitted out the master port. If CTS is low, the opposite slave port has captured the path to the master and any data at the inactive slave port will be lost. For example, if both slave ports are inactive and have RTS low, CTS will be high at both slave ports, indicating that the path is available. As soon as one slave port captures the path by either beginning its transmission or raising its RTS line, the CTS signal at the opposite slave port will drop to the low state. The RTS output on the pin 7 of the master port follows the RTS signal level found on the active slave port.

Pinouts

All ports on the 232PTC are configured as RS-232 DCE ports, using DB9 female connectors. Note that a null-modem type connection will be required to connect the 232PTC9 to other DCE configured ports. Tables 1 and 2 and Figure 2 show the configuration of each port.

Master Port Pinouts

SIGNAL	PIN	DIRECTION
TD	3	Input
RD	2	Output
RTS	7	Output
GND	5	*****


Slave Port Pinouts

SIGNAL	PIN	DIRECTION
TD	3	Input
RD	2	Output
RTS	7	Input
CTS	8	Output
GND	5	*****

+ Cascading Port Combiners

Port combiners can be cascaded by connecting the master port of each successive unit to one of the slave ports of the preceding unit. Each additional port combiner adds one slave port to the system.

232PTC9 Port Diagram





Recommended Accessories

Power Supply
SM16-12-V-P230-C1



Serial Cables
9PAMFG



QUICK START GUIDE



232PTC9

RS-232 2-Port Combiner

Before you begin, be
sure you have the following:

- + 232PTC9
- + AC to DC Power Adapter
(required but not included)

B+B SMARTWORX

Powered by

ADVANTECH

1-888-948-2248 | Europe: +353 91 792444

advantech-bb.com

707 Dayton Road | PO Box 1040 | Ottawa, IL 61350
Phone: 815-433-5100 | Fax: 815-433-5109

www.advantech-bb.com | E-mail: support@advantech-bb.com

B+B SMARTWORX

Powered by

ADVANTECH

Fast and easy on the web: www.advantech-bb.com